

# How to find MAC Addresses for Streaming and Gaming Devices

## Amazon

### Amazon Echo

1. Download the Amazon Alexa app to your phone or computer from the app store.
2. Sign in with your Amazon account.
3. On your phone connect to the wireless network transmitted by your Echo device.
4. The wireless MAC address for your Echo can be found at the bottom of the Echo Setup screen in the Alexa app.

### Fire Stick

1. From the Amazon app, visit the **Home** screen
2. Choose **Settings**
3. Choose **My Fire TV or Device**
4. Choose **About**
5. Choose **Network**
6. The wifi MAC address should be located under **MAC Address (Wi-Fi)**

## Streaming Devices

### Apple TV

1. With your Apple TV remote, navigate to the Settings icon and select it.
2. From the **Settings** menu, select **General**
3. Select **Network**
4. Your MAC Address will be next to either **Wi-Fi Address** or **Ethernet Address** depending on whether you are connected to the internet via Wi-Fi or a wired connection.

### Roku/Roku Express

1. On the back on your Roku there are a pair of six 2-digit pairs separated by colons, e.g. 00:0D:0A:1H:3G:5C. One set is for the Ethernet connector and for the other for the wireless connector.
2. Alternatively, from the Roku home screen, select **Settings** > **Network** > locate the value next to **Wireless MAC Address**

### Smart TV/Bluray Player

1. Most MAC Addresses can be obtained from the **Settings Menu**, either under the **Network** or **About** sections
2. Alternatively, check with the manufacturer for instructions on how to obtain the MAC Address for your specific model

## **Nintendo Consoles**

### **Nintendo DS**

To locate the MAC Address from a Nintendo DS, you must first insert a Nintendo Wi-Fi Connection compatible game and access the WFC Setup Utility. Please note that the exact steps to access the setup utility varies by game. However, the setup utility is a standard menu, included with all WFC-compatible games.

1. After accessing the utility, tap **Options**, then **System Information**
2. The MAC Address and Nintendo WFC ID will be listed on the screen. Unless the game player has successfully connected with Nintendo Wi-Fi Connection, the WFC ID will be blank

### **Nintendo 3DS**

1. From the HOME menu, highlight and select the **System Settings** Icon
2. Select **Internet Settings**
3. Tap **Other Information**
4. Tap **Confirm MAC Address**. Your system's MAC Address will be displayed on the screen

### **Wii U**

1. From the Wii U Menu, select **System Settings**
2. Using the Left Stick select the **Internet icon** and press the A Button
3. Select View MAC Address and wait a moment for the MAC Address to be displayed

### **Nintendo Switch**

1. From the Switch's Home menu, go to **System Settings**
2. Scroll down and select **Internet**
3. The MAC address will appear under System MAC Address

## **Microsoft Consoles**

### **Xbox 360**

1. Select **System Settings**
2. Select **Network Settings**

3. Select **Configure Network**
4. Under **Basic Settings** check to make sure IP Settings is set to Automatic
5. Go to **Additional Settings**
6. Select **Advanced Settings**
7. The MAC Addresses for the wired and wireless adapters should be displayed

### **Xbox One**

1. Navigate to **My Games and Apps**
2. Select **Settings**
3. Select **Network**
4. Select **Advanced Settings**
5. The MAC Addresses for the wired and wireless adapters should be displayed

### **Xbox Series X or Series S**

1. Navigate to the **Settings** page.
2. Select **Network**
3. Select **Advanced Settings**
4. Under **IP settings**, the MAC address will be listed next to **Wired MAC** and **Wireless MAC** on the right-hand side of the screen (this is also where the IP address and other information is located).

### **Sony Consoles**

#### **Playstation 3**

1. From the main menu, select **Settings**
2. Select **System Settings**
3. Select **System Information**
4. The MAC Address will then be displayed on the screen

#### **Playstation 4**

1. Arrow up and over to **Settings** in the PS4 menu
2. Scroll down to **Network**
3. Scroll down to **View Connection Status**
4. The MAC Address will be listed next to MAC Address

#### **Playstation 5**

1. From the Playstation Home screen, select **Settings** in the upper right
2. Select **System**
3. Select **System Software**
4. Select **Console Information**
5. The MAC address will be listed by **MAC Address(Wi-Fi)**